

# PUMP ALL IN ONE HPP

HIGH PERFORMANCE PLASTIC

**120**  
PSI 80-120 PSI  
80-120 PSI

**Manometer**  
Pressure gauge

**Twist-Lock-Ventilkopf**  
Twist-Lock-Head

**Halterung inklusive**  
Bracket included

**Umschaltbar: High-Volume <-> High-Pressure**  
Switchable from high-volume to high-pressure




**HPP** High Performance Plastik  
High Performance Plastic

**PRESTA** Presta Ventilkopf  
Presta valve

**SCHRADER** Schrader Ventilkopf  
Schrader valve

**DUNLOP** Dunlop Ventilkopf  
Dunlop valve

## BEDIENUNG / INSTRUCTION



1. Wählen zwischen High-Pressure und High-Volume /  
Choose between high-pressure and high-volume
2. Befestigen am Ventil / Engage to valve
3. Verriegeln / Lock
4. Aufpumpen / Pump
5. Entriegeln / Unlock
6. Lösen vom Ventil / Remove from valve